

TEXAS A&M HIGH PERFORMANCE RESEARCH COMPUTING

RNA-seq and Differential Expression

16 April 2024



High Performance
Research Computing
DIVISION OF RESEARCH




Course Outline

- Commonly used RNA-seq applications
- RNA-seq library preparation strategies
- Experimental design considerations for differential expression
- Accessing the ACES cluster
- Command line tools (including QC, genome alignment, sorting/binary conversion, and count generation)
- Differential expression analysis and visualization in R


RNA-seq Applications

- Transcriptome Assembly
 - *de novo*: Trinity, Oases, SOAPdenovo-Trans
 - Reference-based: Trinity, StringTie, Cufflinks
- Splice-aware alignment
 - HISAT2
 - STAR
 - Clara Parabricks (GPU-accelerated STAR)
 - TopHat




RNA-seq Applications

- File conversion and formatting
 - SAMtools
 - Picard tools
- Variant Calling
 - GATK (HaplotypeCaller in RNA-seq mode)
- Scaffolding Assemblies
 - L_RNA_scaffolder
 - Rascaf




Spatial Transcriptomics - 10X Genomics



Human breast ductal carcinoma in situ

10X GENOMICS

What's lying beneath the surface?



Visium reveals the complex environment


© 10X GENOMICS, INC. 2021 | FOR RESEARCH USE ONLY. NOT FOR USE IN DIAGNOSTIC PROCEDURES.

9

Sequencing RNA

- Poly-A selection
 - Enriches for mRNA
- Ribosomal depletion
 - Removes rRNA
 - Leaves mRNA, lncRNA, and pre-RNA
- Size selection
 - Used for smRNA (e.g. miRNA)

Kukurba and
Montgomery, 2016




Experimental Design (for Differential Expression)

- Sequencing Depth
 - Minimum 30 million aligned reads per replicate (ENCODE)
 - 30-60 million reads per replicate (Illumina)
- Replicate Number
 - 3 replicates per condition minimum (will likely recover 20-40% of true DEGs)
 - Schurch et al. (2016) suggest 6 replicates per condition minimum, 12 replicates per condition optimal

Experimental Design (for Differential Expression)


- **Biological Replicates**

- Independent samples from different populations or individuals



- **Technical Replicates**

- Multiple libraries from the same individual




Experimental Design (for Differential Expression)

Replicates - Which to use?

- Biological replicates generally increase statistical power more than technical replicates
- Biological variability > Technical Variability
- Biological replicates contain both biological and technical variability

Accessing the HPRC ACES Portal



HPRC webpage: <https://hprc.tamu.edu>

Accessing ACES via the Portal (ACCESS)

Log-in using your ACCESS credentials.


The screenshot shows the ACCESS portal interface. At the top left is the ACCESS logo, and at the top right is the 'Powered By CILogon' logo. Below the header is a teal bar with the text 'Consent to Attribute Release'. Underneath is a white box containing the text: 'TAMU FASTER ACCESS.OOD requests access to the following information. If you do not approve this request, do not proceed.' followed by a list of requested attributes: 'Your CILogon user identifier', 'Your name', 'Your email address', and 'Your username and affiliation from your identity provider'. Below this is a teal bar with the text 'Select an Identity Provider'. Underneath is a white box containing a dropdown menu with the text 'ACCESS CI (XSEDE)' and a question mark icon. Below the dropdown is a checkbox labeled 'Remember this selection' and a 'Log On' button. At the bottom of the white box is the text 'By selecting "Log On", you agree to the privacy policy.' At the bottom of the screenshot is a footer with links for 'For questions about this site, please see the FAQs or send email to help@cilogon.org', 'Know your responsibilities for using the CILogon Service.', and 'See acknowledgements for support for this site.'

The screenshot shows the ACCESS portal login interface. At the top left is the ACCESS logo, and at the top right is the CILogon logo. Below the header is a teal bar with the text 'Login to CILogon'. Underneath is a white box containing two input fields: 'ACCESS Username' and 'ACCESS Password'. Below the input fields is a checkbox labeled 'Don't Remember Login' and a 'Login' button. To the right of the input fields is the CILogon logo and the text 'CILogon facilitates secure access to CyberInfrastructure (CI)'. Below the CILogon logo is a list of links: 'If you had an XSEDE account, please enter your XSEDE username and password for ACCESS login', 'Register for an ACCESS Account', 'Forgot your password?', and 'Need Help?'. At the bottom of the screenshot is a footer with the text 'Click Here for Assistance'.

This is a close-up of the 'Select an Identity Provider' dropdown menu. The dropdown is open, showing the text 'ACCESS CI (XSEDE)' and a question mark icon. The dropdown is highlighted with a red border.

Select the Identity Provider appropriate for your account.

Accessing ACES shell in OOD Portal



Accessing ACES shell in OOD Portal

```
=====
| Texas A&M University High Performance Research Computing |
|-----|
| Website:          https://hprc.tamu.edu |
| Consulting:       help@hprc.tamu.edu (preferred) or (979) 845-0219 |
| ACES Documentation: https://hprc.tamu.edu/kb/User-Guides/ACES |
| FASTER Documentation: https://hprc.tamu.edu/kb/User-Guides/FASTER |
| Grace Documentation: https://hprc.tamu.edu/kb/User-Guides/Grace |
| Terra Documentation: https://hprc.tamu.edu/kb/User-Guides/Terra |
| YouTube Channel:  https://www.youtube.com/texasamhprc |
|-----|
|=====|

*****
*          === IMPORTANT POLICY INFORMATION ===          *
* - Unauthorized use of HPRC resources is prohibited and subject to *
*   criminal prosecution. *
* - Use of HPRC resources in violation of United States export control *
*   laws and regulations is prohibited. Current HPRC staff members are *
*   US citizens and legal residents. *
* - Sharing HPRC account and password information is in violation of *
*   Texas State Law. Any shared accounts will be DISABLED. *
* - Authorized users must also adhere to ALL policies at: *
*   https://hprc.tamu.edu/policies/ *
*****

!! WARNING: THERE ARE ONLY NIGHTLY BACKUPS OF USER HOME DIRECTORIES. !!

Please restrict usage to 8 CORES across ALL login nodes.
Users found in violation of this policy will be SUSPENDED.

To see these messages again, run the motd command.
Your current disk quotas are:
Disk          Disk Usage      Limit    File Usage      Limit
/home/u.wb109972 1.6G      10.0G      4746      10000
/scratch/user/u.wb109972 1.1T      5.0T      98855     250000
Type 'showquota' to view these quotas again.
[u.wb109972@aces-login1 ~]$
```

Example Data

- Create a new directory in your scratch space


```
$ mkdir $SCRATCH/RNA_class
```

- Change your working directory to the one you just created

```
$ cd $SCRATCH/RNA_class
```


- Copy the example data to your directory

```
$ cp -r /scratch/training/rna-seq/* .
```



Quality Control

- NGS libraries should be assessed for adapter content and low-quality reads before downstream analysis
- Low-quality bases and adapters can introduce errors and reduce map rates
- Avoid overly aggressive trimming practices



Quality Control

- Will use FastQC to examine the quality of our example data
- Look for the appropriate module on ACES:

```
$ module spider fastqc
```

- Clear any previously loaded modules and load FastQC:

```
$ module purge
```

```
$ module load FastQC/0.11.9-Java-11
```


Running jobs on ACES


- Small jobs can be run on the login nodes (< 60 minutes, up to 8 cores)
- Larger jobs should be submitted to the compute nodes:
 - Slurm job scheduler
 - Can specify computing requirements:
 - Amount of memory required
 - Number of cores
 - Which modules to load
- Template job scripts are available:
 - <https://hprc.tamu.edu/kb/Software/useful-tools/GCATemplates/>

Quality Control

- Run FastQC on our example fastqs:



```
$ fastqc -t 2 -o . Control1_R1.fastq.gz Control1_R2.fastq.gz
```

- Go to “Files” tab in ACES portal and navigate to the RNA_class directory
- FastQC results saved as html files

[illegible]


FASTQ Format

```
@ERR504787.2.1 M00368:15:000000000-AOHKH:1:5:21261:10968-1 length=100  
GATCGGAAGAGCACACGTCTGAACTCCAGTCACGATCAGATCTCGTATGCCGTCTTCTGCTTGAAAAAACAATAATGCCGTAAA  
+ERR504787.2.1 M00368:15:000000000-AOHKH:1:5:21261:10968-1 length=100  
  
=:4AD=B8A:+<A::1<:AE<C3?*F<B????:8:6?B*9BD;/638.-'-.@7=).=A:6?DDDCBBBB9555&&) + (( (+2&&+((( ( (&&+  
@ERR504787.3.1 M00368:15:000000000-AOHKH:1:3:12724:25677-1 length=100  
GATGTTTTGTTACTGATTGGAACCATGATTGGTGCTTTACTTGGTTTCTTCCTATTTAACCAAGCCTGCCAAAGTATTTATGGGAGATGTAGGTAGTT  
+ERR504787.3.1 M00368:15:000000000-AOHKH:1:3:12724:25677-1 length=100  
  
BCCFFDEFFHHHHHJJJJIJJJJJJJJIIJJFHIIJJJIJJJJJJJJIIJJJIJJJJJJFHHJJJJIIJJHH=CHHFFFFFFEDDEDDEEEDCCDCE
```



Failed QC Examples



Example 1. Failed per base sequence quality - expired MiSeq kit



Failed QC Examples

Example 2. Faulty flowcell


MiSeq flowcell



good quality  poor quality

Failed QC Examples


Example 3. Contamination



Library Trimming


dscDNA 

Read 1 from sequencer



100 bases

Read 2 from sequencer




100 bases




Trimming with TrimGalore!

Read 1 from sequencer



100 bases

Read 2 from sequencer



50 bases

- Specify minimum read length (default = 20)
- Return only paired or retain unpaired

Library Trimming

- Remove loaded modules:

```
$ module purge
```

- Find and load the appropriate modules:

```
$ module spider trim_galore
```

```
$ module load GCCcore/11.2.0 Trim_Galore/0.6.10
```

- Run Trim_Galore!

```
$ trim_galore --paired --fastqc \  
    Controll_R1.fastq.gz Controll_R2.fastq.gz
```

Aligning Reads to a Reference Genome

- Popular splice-aware aligners
 - STAR (now available for GPUs!)
 - HISAT2
- Alignment software needs to have an indexed genome (software specific)
 - Only needs to be done once
 - HPRC maintains indexed genomes for popular aligners
 - Email help@hprc.tamu.edu if you would like us to add another indexed genome

Aligning Reads to a Reference Genome

- Clear any previously loaded modules:

```
$ module purge
```

- Search for and load the appropriate modules:

```
$ module spider hisat
```

```
$ module load GCC/11.3.0 OpenMPI/4.1.4 HISAT2/2.2.1
```

- Get information on how to run the program:

```
$ hisat2 -h
```

Aligning Reads to a Reference Genome

- Align our trimmed reads to the mouse genome:
 - Path to previously indexed genome:

```
/scratch/data/bio/mm39/GCF_000001635.27_GRCm39_genomic
```

- Set the path to the indexed genome as a new variable:

```
$ idx_genome=/path/to/genome
```

- Run the HISAT2 command

```
$ hisat2 -x $idx_genome -p 2 \  
  -1 Control1_R1_val_1.fq.gz \  
  -2 Control1_R2_val_2.fq.gz \  
  -S Control1.sam
```

Aligning Reads to a Reference Genome

```
236499 reads; of these:
  236499 (100.00%) were paired; of these:
    30736 (13.00%) aligned concordantly 0 times
    197200 (83.38%) aligned concordantly exactly 1 time
    8563 (3.62%) aligned concordantly >1 times
    ----
    30736 pairs aligned concordantly 0 times; of these:
    3583 (11.66%) aligned discordantly 1 time
    ----
    27153 pairs aligned 0 times concordantly or discordantly; of these:
    54306 mates make up the pairs; of these:
      30660 (56.46%) aligned 0 times
      21188 (39.02%) aligned exactly 1 time
      2458 (4.53%) aligned >1 times
93.52% overall alignment rate
```

Processing Alignment Files

- Alignment files may need to be modified and/or converted before any downstream analyses:
 - Sorting (name or pos/coord)
 - Adding read groups
 - Converting to binary format
- We will use SAMtools to process our alignment file:

```
$ module purge
```

```
$ module spider SAMtools
```

```
$ module spider SAMtools/1.17
```

```
$ module load GCC/12.2.0 SAMtools/1.17
```

Processing Alignment Files

- Run SAMtools sort to convert and sort the alignment file in one step:

```
$ samtools sort --threads 2 \  
    -o Control1_sorted.bam Control1.sam
```

- Index the new bam file:

```
$ samtools index Control1_sorted.bam
```

Generating Count Files

- There are many packages available to generate read counts:
 - featureCounts
 - GenomicRanges (R package)
 - HTSeq
- Load the required modules and produce the count table:

```
$ module purge
```

```
$ module load GCC/11.3.0 OpenMPI/4.1.4 HTSeq/2.0.2
```

```
$ htseq-count -r pos -i gene Control1_sorted.bam \  
    GCF_000001635.27_GRCm39_genomic.gff > Control1_counts.txt
```


Differential Expression Analysis with DESeq2

Analyzing RNA-seq data with DESeq2

Michael I. Love, Simon Anders, and Wolfgang Huber

10/27/2021

Abstract


A basic task in the analysis of count data from RNA-seq is the detection of differentially expressed genes. The count data are presented as a table which reports, for each sample, the number of sequence fragments that have been assigned to each gene. Analogous data also arise for other assay types, including comparative ChIP-Seq, HiC, shRNA screening, and mass spectrometry. An important analysis question is the quantification and statistical inference of systematic changes between conditions, as compared to within-condition variability. The package DESeq2 provides methods to test for differential expression by use of negative binomial generalized linear models; the estimates of dispersion and logarithmic fold changes incorporate data-driven prior distributions. This vignette explains the use of the package and demonstrates typical workflows. [An RNA-seq workflow](#) on the Bioconductor website covers similar material to this vignette but at a slower pace, including the generation of count matrices from FASTQ files. DESeq2 package version: 1.35.0

- [Standard workflow](#)
 - [Quick start](#)
 - [How to get help for DESeq2](#)
 - [Acknowledgments](#)
 - [Funding](#)
 - [Input data](#)
 - [Why un-normalized counts?](#)
 - [The DESeqDataSet](#)
 - [Transcript abundance files and *tximport* / *tximeta*](#)
 - [Tximeta for import with automatic metadata](#)
 - [Count matrix input](#)
 - [htseq-count input](#)
 - [SummarizedExperiment input](#)
 - [Pre-filtering](#)
 - [Note on factor levels](#)
 - [Collapsing technical replicates](#)
 - [About the pasilla dataset](#)
 - [Differential expression analysis](#)

<http://bioconductor.org/packages/devel/bioc/vignettes/DESeq2/inst/doc/DESeq2.html>

RStudio on ACES

- Open RStudio in the “Interactive Apps” tab on the ACES portal



RStudio on ACES

RStudio version: 2023.06.1-524

This app will launch RStudio using the R_tamu software module on an [ACES](#) compute node.

You can install your own R packages directly within RStudio.

R version

4.2.2

Number of hours (max 168)

2

Number of cores (max 96)

1

Total GB memory (max 480)

12

Email

Email address must be provided if the checkbox for email notification is checked (see below).

☐ I would like to receive an email when the session starts

Slurm account (optional)

This field is needed only if you want to use a different account other than your default account. Leave it blank if you don't know what to provide.

Launch

The RStudio session data for this session can be accessed under the data root directory.

- Set the number of hours to 2
- Set the number of cores to 1
- Set the Total GB memory to 12
- Click Launch Button
- Wait for the session to start
- Click “Connect to RStudio Server”

Session was successfully created. X

Home / My Interactive Sessions

Interactive Apps	RStudio (11145) 1 node 1 core Running
GUI	
VNC	Host: ac006
Nextsilicon VNC	Created at: 2023-10-25 15:03:09 CDT
Imaging	Time Remaining: 1 hour and 56 minutes
CryoSPARC	Session ID: 2757dcd-b-e93d-4954-ad3d-270aaa0c804
ImageJ	
... etc	

Connect to RStudio Server

Differential Expression Analysis

Open a new R script and set your working directory

```
setwd("/scratch/user/username/RNA_class/counts")
```

- Let's look at the contents of the directory and the sample table (in the console):

```
> list.files()
```

```
> system("cat sampleTable.csv")
```

Differential Expression Analysis

- Load the all of the required packages:

```
library(ggplot2)
library(pheatmap)
library(DESeq2)
library(EnhancedVolcano)
```

- Highlight this section of code in the script and click “Run”

Differential Expression Analysis

- Read in the sample table and reformat it:

```
sampleTable <- read.csv("sampleTable.csv", header=TRUE)
sampleTable <- as.data.frame(sampleTable)
sampleTable$condition <- factor(sampleTable$condition)
sampleTable
```

- Output:

```
> sampleTable
  sampleName      fileName      condition
1   Control1 Control1_counts.txt      Control
2   Control2 Control2_counts.txt      Control
3   Control3 Control3_counts.txt      Control
4   Control4 Control4_counts.txt      Control
5   Control5 Control5_counts.txt      Control
6       NAD1   NAD1_counts.txt NAD_supplement
7       NAD2   NAD2_counts.txt NAD_supplement
8       NAD3   NAD3_counts.txt NAD_supplement
9       NAD4   NAD4_counts.txt NAD_supplement
10      NAD5   NAD5_counts.txt NAD_supplement
> |
```

Differential Expression Analysis

- Create the dds object

```
dds <- DESeqDataSetFromHTSeqCount(sampleTable = sampleTable,  
                                   directory = ".",  
                                   design = ~ condition)  
dds
```

- Output:

```
> dds  
class: DESeqDataSet  
dim: 46316 10  
metadata(1): version  
assays(1): counts  
rownames(46316): 0610005C13Rik 0610006L08Rik ... n-TYgta9 n-Tcgca44  
rowData names(0):  
colnames(10): Control1 Control2 ... NAD4 NAD5  
colData names(1): condition  
> |
```

Differential Expression Analysis

- Filter out genes with low read counts:

```
keep <- rowSums(counts(dds)) >= 10  
dds <- dds[keep,]
```

- Run the differential expression analysis:

```
dds <- DESeq(dds)  
res <- results(dds)  
res
```


Differential Expression Analysis

DESeq Results Explained:

```
> res
```

```
log2 fold change (MLE): condition NAD supplement vs Control
```

```
Wald test p-value: condition NAD supplement vs Control
```

```
DataFrame with 46316 rows and 6 columns
```

	baseMean <numeric>	log2FoldChange <numeric>	lfcSE <numeric>	stat <numeric>	pvalue <numeric>	padj <numeric>
0610005C13Rik	5.99463012842517	0.847110388480526	1.0536757176372	0.803957398183298	0.4214215791485	0.626767086797856
0610006L08Rik	0.595406936513421	-1.33338402962542	2.80181545117752	-0.475900020133387	0.634145607845708	NA
0610009B22Rik	229.572854136365	-0.46059738889209	0.272726760296267	-1.688860265827	0.0912462113650002	0.227131423458176
0610009E02Rik	52.7148015454124	-1.18516447577791	0.483501805720158	-2.45121003015211	0.0142376849790884	0.058533268492583
0610009L18Rik	5.27096640148362	0.500548878654153	1.0060551707554	0.497536211933899	0.618810973397835	0.779869206330055

Differential Expression Analysis

DESeq Results Explained:

```
> res
```

```
log2 fold change (MLE): condition NAD supplement vs Control
```

```
Wald test p-value: condition NAD supplement vs Control
```

```
DataFrame with 46316 rows and 6 columns
```

	baseMean <numeric>	log2FoldChange <numeric>	lfcSE <numeric>	stat <numeric>	pvalue <numeric>	padj <numeric>
0610005C13Rik	5.99463012842517	0.847110388480526	1.0536757176372	0.803957398183298	0.4214215791485	0.626767086797856
0610006L08Rik	0.595406936513421	-1.33338402962542	2.80181545117752	-0.475900020133387	0.634145607845708	NA
0610009B22Rik	229.572854136365	-0.46059738889209	0.272726760296267	-1.688860265827	0.0912462113650002	0.227131423458176
0610009E02Rik	52.7148015454124	-1.18516447577791	0.483501805720158	-2.45121003015211	0.0142376849790884	0.058533268492583
0610009L18Rik	5.27096640148362	0.500548878654153	1.0060551707554	0.497536211933899	0.618810973397835	0.779869206330055

Mean of normalized
counts for all samples

Differential Expression Analysis

DESeq Results Explained:

```
> res
```

```
log2 fold change (MLE): condition NAD supplement vs Control
```

```
Wald test p-value: condition NAD supplement vs Control
```

```
DataFrame with 46316 rows and 6 columns
```

	baseMean <numeric>	log2FoldChange <numeric>	lfcSE <numeric>	stat <numeric>	pvalue <numeric>	padj <numeric>
0610005C13Rik	5.99463012842517	0.847110388480526	1.0536757176372	0.803957398183298	0.4214215791485	0.626767086797856
0610006L08Rik	0.595406936513421	-1.33338402962542	2.80181545117752	-0.475900020133387	0.634145607845708	NA
0610009B22Rik	229.572854136365	-0.46059738889209	0.272726760296267	-1.688860265827	0.0912462113650002	0.227131423458176
0610009E02Rik	52.7148015454124	-1.18516447577791	0.483501805720158	-2.45121003015211	0.0142376849790884	0.058533268492583
0610009L18Rik	5.27096640148362	0.500548878654153	1.0060551707554	0.497536211933899	0.618810973397835	0.779869206330055

Log2 fold change: NAD
supplement vs Control

Differential Expression Analysis

DESeq Results Explained:

```
> res
```

```
log2 fold change (MLE): condition NAD supplement vs Control
```

```
Wald test p-value: condition NAD supplement vs Control
```

```
DataFrame with 46316 rows and 6 columns
```

	baseMean	log2FoldChange	lfcSE	stat	pvalue	padj
	<numeric>	<numeric>	<numeric>	<numeric>	<numeric>	<numeric>
0610005C13Rik	5.99463012842517	0.847110388480526	1.0536757176372	0.803957398183298	0.4214215791485	0.626767086797856
0610006L08Rik	0.595406936513421	-1.33338402962542	2.80181545117752	-0.475900020133387	0.634145607845708	NA
0610009B22Rik	229.572854136365	-0.46059738889209	0.272726760296267	-1.688860265827	0.0912462113650002	0.227131423458176
0610009E02Rik	52.7148015454124	-1.18516447577791	0.483501805720158	-2.45121003015211	0.0142376849790884	0.058533268492583
0610009L18Rik	5.27096640148362	0.500548878654153	1.0060551707554	0.497536211933899	0.618810973397835	0.779869206330055

Log fold change
standard error

Differential Expression Analysis

DESeq Results Explained:

```
> res
```

```
log2 fold change (MLE): condition NAD supplement vs Control
```

```
Wald test p-value: condition NAD supplement vs Control
```

```
DataFrame with 46316 rows and 6 columns
```

	baseMean <numeric>	log2FoldChange <numeric>	lfcSE <numeric>	stat <numeric>	pvalue <numeric>	padj <numeric>
0610005C13Rik	5.99463012842517	0.847110388480526	1.0536757176372	0.803957398183298	0.4214215791485	0.626767086797856
0610006L08Rik	0.595406936513421	-1.33338402962542	2.80181545117752	-0.475900020133387	0.634145607845708	NA
0610009B22Rik	229.572854136365	-0.46059738889209	0.272726760296267	-1.688860265827	0.0912462113650002	0.227131423458176
0610009E02Rik	52.7148015454124	-1.18516447577791	0.483501805720158	-2.45121003015211	0.0142376849790884	0.058533268492583
0610009L18Rik	5.27096640148362	0.500548878654153	1.0060551707554	0.497536211933899	0.618810973397835	0.779869206330055

Wald statistic: NAD
supplement vs Control

Differential Expression Analysis

DESeq Results Explained:

```
> res
```

```
log2 fold change (MLE): condition NAD supplement vs Control
```

```
Wald test p-value: condition NAD supplement vs Control
```

```
DataFrame with 46316 rows and 6 columns
```

	baseMean <numeric>	log2FoldChange <numeric>	lfcSE <numeric>	stat <numeric>	pvalue <numeric>	padj <numeric>
0610005C13Rik	5.99463012842517	0.847110388480526	1.0536757176372	0.803957398183298	0.4214215791485	0.626767086797856
0610006L08Rik	0.595406936513421	-1.33338402962542	2.80181545117752	-0.475900020133387	0.634145607845708	NA
0610009B22Rik	229.572854136365	-0.46059738889209	0.272726760296267	-1.688860265827	0.0912462113650002	0.227131423458176
0610009E02Rik	52.7148015454124	-1.18516447577791	0.483501805720158	-2.45121003015211	0.0142376849790884	0.058533268492583
0610009L18Rik	5.27096640148362	0.500548878654153	1.0060551707554	0.497536211933899	0.618810973397835	0.779869206330055

Wald test p value
(unadjusted)

Differential Expression Analysis

DESeq Results Explained:

```
> res
```

```
log2 fold change (MLE): condition NAD supplement vs Control
```

```
Wald test p-value: condition NAD supplement vs Control
```

```
DataFrame with 46316 rows and 6 columns
```

	baseMean	log2FoldChange	lfcSE	stat	pvalue	padj
	<numeric>	<numeric>	<numeric>	<numeric>	<numeric>	<numeric>
0610005C13Rik	5.99463012842517	0.847110388480526	1.0536757176372	0.803957398183298	0.4214215791485	0.626767086797856
0610006L08Rik	0.595406936513421	-1.33338402962542	2.80181545117752	-0.475900020133387	0.634145607845708	NA
0610009B22Rik	229.572854136365	-0.46059738889209	0.272726760296267	-1.688860265827	0.0912462113650002	0.227131423458176
0610009E02Rik	52.7148015454124	-1.18516447577791	0.483501805720158	-2.45121003015211	0.0142376849790884	0.058533268492583
0610009L18Rik	5.27096640148362	0.500548878654153	1.0060551707554	0.497536211933899	0.618810973397835	0.779869206330055

BH corrected p
values (corrected
for multiple testing)

Differential Expression Analysis

- How many genes are differentially expressed?

```
sum(res$padj <= 0.05, na.rm = TRUE)
```

- Collect all the DEGs and write them to file:

```
sigGenes <- res[ which(res$padj < 0.05), ]  
sigGenes  
write.csv(sigGenes,  
          "Differentially_Expressed.csv",  
          row.names = TRUE)
```


PCA plot

- Log transform the results and calculate the row variance

```
logTran <- rlog(dds)  
rv <- rowVars(assay(logTran))
```

- Create a list of genes with the greatest variance:

```
select <- order(rv, decreasing = TRUE)[seq_len(min(100, length(rv)))]
```

PCA plot

- Run the principal component analysis (PCA)

```
PCA <- prcomp(t(assay(logTran)[select, ]), scale = FALSE)
summary(PCA)
```

- Output:

```
> summary(PCA)
Importance of components:
      PC1      PC2      PC3      PC4      PC5      PC6      PC7      PC8      PC9      PC10
Standard deviation 13.1129 2.50384 1.94479 1.45805 1.42247 1.24092 1.08253 0.52065 0.38289 3.066e-15
Proportion of Variance 0.9084 0.03312 0.01998 0.01123 0.01069 0.00814 0.00619 0.00143 0.00077 0.000e+00
Cumulative Proportion 0.9084 0.94156 0.96154 0.97278 0.98347 0.99160 0.99779 0.99923 1.00000 1.000e+00
> |
```

PCA plot

- Set up the PCA for ggplot2

```
percentVar <- round(100*PCA$sdev^2/sum(PCA$sdev^2), 1)
ggPCA_out <- as.data.frame(PCA$x)
ggPCA_out <- cbind(ggPCA_out, sampleTable)
head(ggPCA_out)
```

- Output:


```
> head(ggPCA_out)
      PC1      PC2      PC3      PC4      PC5      PC6      PC7      PC8      PC9
Control1 -12.576882  0.679757091  1.4677571  1.4408177 -0.9772907 -2.58170153 -0.8901816  0.12856743  0.057730319
Control2 -11.362119 -0.789437801 -4.1149258  0.5846590 -1.6247299  0.15350772  1.1461662 -0.21539578  0.001565017
Control3 -12.038043  0.002152241  0.5811305 -3.0992919  1.4657618 -0.97863917  1.0515499 -0.04523746 -0.046467189
Control4 -13.139919  0.487982477  0.6723550  2.2531953  2.6066210  1.29314839  0.3152618 -0.07647994  0.001933003
Control5 -12.530993  0.265744874  1.7077315 -1.1646465 -1.8470308  2.10751112 -1.1715371  0.07993858 -0.013573324
NAD1      8.795471  0.517771986 -2.7475597 -0.6142266  1.1887028 -0.04330035 -1.5880439  0.71154077  0.323683075
      PC10 sampleName      fileName      condition
Control1 3.175046e-15 Control1 Control1_counts.txt Control
Control2 2.950899e-15 Control2 Control2_counts.txt Control
Control3 2.730071e-15 Control3 Control3_counts.txt Control
Control4 3.300727e-15 Control4 Control4_counts.txt Control
Control5 2.949020e-15 Control5 Control5_counts.txt Control
NAD1      2.826141e-15      NAD1      NAD1_counts.txt NAD_supplement
> |
```

PCA plot

- Plot the PCA

```
ggplot(ggPCA_out, aes(x=PC1,y=PC2,color=condition)) +  
  geom_point(size=4) +  
  labs(x = paste0("PC1 - variance explained: ", percentVar[1], "%"),  
       y = paste0("PC2 - variance explained: ", percentVar[2], "%")) +  
  theme_bw()
```

PCA plot




Volcano Plot

```
EnhancedVolcano(res,  
                lab = rownames(res),  
                x = 'log2FoldChange',  
                y = 'padj',  
                pCutoff = 0.05,  
                FCcutoff = 1.0,  
                pointSize = 3.0,  
                labSize = 4.0,  
                colAlpha = 1/2,  
                drawConnectors = FALSE,  
                legendPosition = "right")
```

Volcano plot

EnhancedVolcano



total = 23595 variables

Heatmap

- Reorder the results based on adjusted p-values
- Assign genes with adjusted p-values below 0.05 and absolute log2 fold changes ≥ 6.5 to the variable 'sig'

```
resorted_deresults <- res[order(res$padj),]  
sig <- resorted_deresults[!is.na(resorted_deresults$padj) &  
                           resorted_deresults$padj < 0.05 &  
                           abs(resorted_deresults$log2FoldChange) >=  
6.5,]
```


Heatmap

- Assign the gene names from 'sig' to a new variable named 'selected'
- We will use the list of gene names for the heatmap

```
selected <- rownames(sig)
selected
```


```
> selected
[1] "Kcnip1"      "Kcnk9"       "Grin2a"      "Slc6a7"      "LOC118567965" "Lyz2"
[7] "Pou3f3"      "Kcnj5"       "Mal2"        "8030451A03Rik" "Gm30223"      "Fibcd1"
[13] "Gm3687"      "Shh"         "Mgat4c"      "Cntnap5c"    "Epha6"        "Cybb"
[19] "Dcn"
> |
```

Heatmap

- We need to normalize the data
- Then we can create a heatmap using the pheatmap package

```
transformed_readcounts <- normTransform(dds)
pheatmap(assay(transformed_readcounts)[selected,],
         cluster_rows = TRUE, show_rownames = TRUE,
         cluster_cols = TRUE,
         labels_col = colData(dds)$sampleName)
```

Heatmap



Thank You!

Need Help? Contact the HPRC Helpdesk

Website: hprc.tamu.edu

Email: help@hprc.tamu.edu

Phone: (979) 845-0219

Help us help you -- we need more info

- Which Cluster (ACES, FASTER, Terra, Grace)
- Username
- Job id(s) if any
- Location of your jobfile, input/output files
- Application used, if any
- Module(s) loaded, if any
- Error messages
- Steps you have taken, so we can reproduce the problem

60

